

# **OsmoPCU VTY Reference**

Copyright © 2014

This work is copyright by sysmocom - s.f.m.c. GmbH. All rights reserved.

**COLLABORATORS**

|               |   |                |                  |
|---------------|---|----------------|------------------|
|               | <i>TITLE :</i><br>OsmoPCU VTY Reference |                |                  |
| <i>ACTION</i> | <i>NAME</i>                             | <i>DATE</i>    | <i>SIGNATURE</i> |
| WRITTEN BY    |   | April 29, 2021 |                  |

**REVISION HISTORY**

| NUMBER | DATE           | DESCRIPTION                 | NAME |
|--------|----------------|-----------------------------|------|
| v1     | 5th March 2014 | Initial version for 0.2-307 | hf   |

# Contents

|          |   |          |
|----------|---|----------|
| <b>1</b> | <b>VTY reference</b>  | <b>1</b> |
| 1.1      | Common Commands   | 1        |
| 1.1.1    | end   | 2        |
| 1.1.2    | exit  | 2        |
| 1.1.3    | help  | 2        |
| 1.1.4    | list [with-flags]   | 2        |
| 1.1.5    | show running-config   | 3        |
| 1.1.6    | show vty-attributes   | 3        |
| 1.1.7    | show vty-attributes (application library global)  | 3        |
| 1.1.8    | write   | 4        |
| 1.1.9    | write file [PATH]   | 4        |
| 1.1.10   | write memory  | 4        |
| 1.1.11   | write terminal  | 4        |
| 1.2      | view  | 5        |
| 1.2.1    | enable [expert-mode]  | 5        |
| 1.2.2    | logging color (0 1)   | 5        |
| 1.2.3    | logging disable   | 5        |
| 1.2.4    | logging enable  | 6        |
| 1.2.5    | logging filter all (0 1)  | 6        |
| 1.2.6    | logging level (csn ll if rlc mac rlc mac data rlc mac dll rlc mac ull rlc mac sched rlc mac ... | 6        |
| 1.2.7    | logging level force-all (debug info notice error fatal)   | 9        |
| 1.2.8    | logging level set-all (debug info notice error fatal)   | 10       |
| 1.2.9    | logging print category (0 1)  | 10       |
| 1.2.10   | logging print category-hex (0 1)  | 11       |
| 1.2.11   | logging print extended-timestamp (0 1)  | 11       |
| 1.2.12   | logging print file (0 1 basename) [last]  | 12       |
| 1.2.13   | logging print level (0 1)   | 12       |
| 1.2.14   | logging print thread-id (0 1)   | 13       |
| 1.2.15   | logging set-log-mask MASK   | 13       |
| 1.2.16   | logging timestamp (0 1)   | 13       |

|        |   |    |
|--------|---|----|
| 1.2.17 | logp (csn1ll1ifrlcmacrllcmacdata rlcmacd rlcmacullrlcmacsched rlcmacmeas tbf t... | 14 |
| 1.2.18 | no logging level force-all  | 16 |
| 1.2.19 | show alarms   | 17 |
| 1.2.20 | show asciidoc counters  | 17 |
| 1.2.21 | show bts pdch   | 17 |
| 1.2.22 | show bts statistics   | 18 |
| 1.2.23 | show bts-timer [TNNNN]  | 18 |
| 1.2.24 | show cpu-sched threads  | 18 |
| 1.2.25 | show fsm NAME   | 19 |
| 1.2.26 | show fsm all  | 19 |
| 1.2.27 | show fsm-instances NAME   | 19 |
| 1.2.28 | show fsm-instances all  | 20 |
| 1.2.29 | show history  | 20 |
| 1.2.30 | show logging vty  | 20 |
| 1.2.31 | show ms all   | 21 |
| 1.2.32 | show ms imsi IMSI   | 21 |
| 1.2.33 | show ms tlli TLLI   | 21 |
| 1.2.34 | show online-help  | 22 |
| 1.2.35 | show rate-counters  | 22 |
| 1.2.36 | show stats  | 22 |
| 1.2.37 | show stats level (global peer subscriber)   | 23 |
| 1.2.38 | show talloc-context (application all) (full brief DEPTH)                          | 23 |
| 1.2.39 | show talloc-context (application all) (full brief DEPTH) filter REGEXP            | 24 |
| 1.2.40 | show talloc-context (application all) (full brief DEPTH) tree ADDRESS             | 24 |
| 1.2.41 | show tbf (all ccch pacch)   | 25 |
| 1.2.42 | show timer [TNNNN]  | 25 |
| 1.2.43 | show version  | 26 |
| 1.2.44 | terminal length <0-512>   | 26 |
| 1.2.45 | terminal no length  | 26 |
| 1.2.46 | who   | 27 |
| 1.3    | enable  | 27 |
| 1.3.1  | configure terminal  | 27 |
| 1.3.2  | copy running-config startup-config  | 27 |
| 1.3.3  | disable   | 28 |
| 1.3.4  | logging color (0 1)   | 28 |
| 1.3.5  | logging disable   | 28 |
| 1.3.6  | logging enable  | 29 |
| 1.3.7  | logging filter all (0 1)  | 29 |
| 1.3.8  | logging level (csn1ll1ifrlcmacrllcmacdata rlcmacd rlcmacullrlcmacsched rlcmacm... | 29 |

|        |   |    |
|--------|---|----|
| 1.3.9  | logging level force-all (debug info notice error fatal)                                     | 32 |
| 1.3.10 | logging level set-all (debug info notice error fatal)                                       | 33 |
| 1.3.11 | logging print category (0 1)  | 33 |
| 1.3.12 | logging print category-hex (0 1)  | 34 |
| 1.3.13 | logging print extended-timestamp (0 1)  | 34 |
| 1.3.14 | logging print file (0 1 basename) [last]  | 35 |
| 1.3.15 | logging print level (0 1)   | 35 |
| 1.3.16 | logging print thread-id (0 1)   | 36 |
| 1.3.17 | logging set-log-mask MASK   | 36 |
| 1.3.18 | logging timestamp (0 1)   | 36 |
| 1.3.19 | logp (csn l l1 f rlc mac rlc macdata rlc macd rlc macu rlc macs sched rlc mac meas tbf t... | 37 |
| 1.3.20 | no logging level force-all  | 39 |
| 1.3.21 | show alarms   | 40 |
| 1.3.22 | show asciidoc counters  | 40 |
| 1.3.23 | show bts pdch   | 40 |
| 1.3.24 | show bts statistics   | 41 |
| 1.3.25 | show bts-timer [TNNNN]  | 41 |
| 1.3.26 | show cpu-sched threads  | 41 |
| 1.3.27 | show fsm NAME   | 42 |
| 1.3.28 | show fsm all  | 42 |
| 1.3.29 | show fsm-instances NAME   | 42 |
| 1.3.30 | show fsm-instances all  | 43 |
| 1.3.31 | show history  | 43 |
| 1.3.32 | show logging vty  | 43 |
| 1.3.33 | show ms all   | 44 |
| 1.3.34 | show ms imsi IMSI   | 44 |
| 1.3.35 | show ms tlli TLLI   | 44 |
| 1.3.36 | show online-help  | 45 |
| 1.3.37 | show rate-counters  | 45 |
| 1.3.38 | show startup-config   | 45 |
| 1.3.39 | show stats  | 45 |
| 1.3.40 | show stats level (global peer subscriber)   | 46 |
| 1.3.41 | show talloc-context (application all) (full brief DEPTH)                                    | 46 |
| 1.3.42 | show talloc-context (application all) (full brief DEPTH) filter REGEXP                      | 47 |
| 1.3.43 | show talloc-context (application all) (full brief DEPTH) tree ADDRESS                       | 47 |
| 1.3.44 | show tbf (all ccch pacch)   | 48 |
| 1.3.45 | show timer [TNNNN]  | 48 |
| 1.3.46 | show version  | 49 |
| 1.3.47 | stats report  | 49 |

|        |   |    |
|--------|---|----|
| 1.3.48 | stats reset . . . . .   | 49 |
| 1.3.49 | terminal length <0-512> . . . . .                                       | 50 |
| 1.3.50 | terminal monitor . . . . .  | 50 |
| 1.3.51 | terminal no length . . . . .  | 50 |
| 1.3.52 | terminal no monitor . . . . .   | 51 |
| 1.3.53 | who . . . . .   | 51 |
| 1.4    | config . . . . .  | 51 |
| 1.4.1  | banner motd default . . . . .   | 51 |
| 1.4.2  | banner motd file [FILE] . . . . .                                       | 52 |
| 1.4.3  | cpu-sched . . . . .   | 52 |
| 1.4.4  | enable password (8l) WORD . . . . .                                     | 52 |
| 1.4.5  | enable password LINE . . . . .  | 53 |
| 1.4.6  | hostname WORD . . . . .   | 53 |
| 1.4.7  | line vty . . . . .  | 53 |
| 1.4.8  | log alarms <2-32700> . . . . .  | 54 |
| 1.4.9  | log file .FILENAME . . . . .  | 54 |
| 1.4.10 | log gsmtap [HOSTNAME] . . . . .   | 54 |
| 1.4.11 | log stderr . . . . .  | 55 |
| 1.4.12 | log syslog (authpriv cron daemon ftp lpr mail news user uucp) . . . . . | 55 |
| 1.4.13 | log syslog local <0-7> . . . . .  | 56 |
| 1.4.14 | log systemd-journal [raw] . . . . .                                     | 56 |
| 1.4.15 | no banner motd . . . . .  | 56 |
| 1.4.16 | no enable password . . . . .  | 57 |
| 1.4.17 | no hostname [HOSTNAME] . . . . .  | 57 |
| 1.4.18 | no log alarms . . . . .   | 57 |
| 1.4.19 | no log file .FILENAME . . . . .   | 58 |
| 1.4.20 | no log stderr . . . . .   | 58 |
| 1.4.21 | no log syslog . . . . .   | 58 |
| 1.4.22 | no log systemd-journal . . . . .  | 59 |
| 1.4.23 | no service advanced-vty . . . . .                                       | 59 |
| 1.4.24 | no service terminal-length [<0-512>] . . . . .                          | 59 |
| 1.4.25 | no stats reporter log . . . . .   | 60 |
| 1.4.26 | no stats reporter statsd . . . . .                                      | 60 |
| 1.4.27 | password (8l) WORD . . . . .  | 60 |
| 1.4.28 | password LINE . . . . .   | 61 |
| 1.4.29 | pcu . . . . .   | 61 |
| 1.4.30 | service advanced-vty . . . . .  | 61 |
| 1.4.31 | service terminal-length <0-512> . . . . .                               | 62 |
| 1.4.32 | show history . . . . .  | 62 |

|        |  |    |
|--------|--|----|
| 1.4.33 | stats interval <0-65535>   | 62 |
| 1.4.34 | stats reporter log   | 63 |
| 1.4.35 | stats reporter statsd  | 63 |
| 1.5    | config-log   | 63 |
| 1.5.1  | logging color (01)   | 63 |
| 1.5.2  | logging filter all (01)  | 64 |
| 1.5.3  | logging level (csn1ll1flrlcmacrlecmacdatalecmacdllrlcmacullrlcmacschedlecmacm... | 64 |
| 1.5.4  | logging level force-all (debuglinfolnoticeleerrorlfatal)                         | 67 |
| 1.5.5  | logging level set-all (debuglinfolnoticeleerrorlfatal)                           | 68 |
| 1.5.6  | logging print category (01)  | 68 |
| 1.5.7  | logging print category-hex (01)  | 69 |
| 1.5.8  | logging print extended-timestamp (01)  | 69 |
| 1.5.9  | logging print file (01 basename) [last]  | 70 |
| 1.5.10 | logging print level (01)   | 70 |
| 1.5.11 | logging print thread-id (01)   | 71 |
| 1.5.12 | logging timestamp (01)   | 71 |
| 1.5.13 | no logging level force-all   | 71 |
| 1.6    | config-stats   | 72 |
| 1.6.1  | disable  | 72 |
| 1.6.2  | enable   | 72 |
| 1.6.3  | flush-period <0-65535>   | 72 |
| 1.6.4  | level (global peer subscriber)   | 73 |
| 1.6.5  | local-ip ADDR  | 73 |
| 1.6.6  | mtu <100-65535>  | 73 |
| 1.6.7  | no local-ip  | 74 |
| 1.6.8  | no mtu   | 74 |
| 1.6.9  | no prefix  | 74 |
| 1.6.10 | prefix PREFIX  | 74 |
| 1.6.11 | remote-ip ADDR   | 75 |
| 1.6.12 | remote-port <1-65535>  | 75 |
| 1.7    | config-line  | 75 |
| 1.7.1  | bind A.B.C.D [<0-65535>]   | 75 |
| 1.7.2  | login  | 76 |
| 1.7.3  | no login   | 76 |
| 1.8    | config-cpu-sched   | 76 |
| 1.8.1  | cpu-affinity (self all <0-4294967295> THREADNAME) CPUHEXMASK [delay]             | 76 |
| 1.8.2  | policy rr <1-32>   | 77 |
| 1.9    | config-pcu   | 77 |
| 1.9.1  | alloc-algorithm (alb dynamic)  | 77 |



|        |   |    |
|--------|---|----|
| 1.9.2  | cs <1-4> [<1-4>]  | 78 |
| 1.9.3  | cs downgrade-threshold <1-10000>  | 78 |
| 1.9.4  | cs link-quality-ranges cs1 <0-35> cs2 <0-35> <0-35> cs3 <0-35> <0-35> cs4 <0-35>    | 79 |
| 1.9.5  | cs max <1-4> [<1-4>]  | 80 |
| 1.9.6  | cs threshold <0-100> <0-100>  | 80 |
| 1.9.7  | dl-tbf-preemptive-retransmission  | 81 |
| 1.9.8  | egprs dl arq-type (spblarq2)  | 81 |
| 1.9.9  | flow-control bucket-time <1-65534>  | 82 |
| 1.9.10 | flow-control force-bvc-bucket-size <1-6553500>                                      | 82 |
| 1.9.11 | flow-control force-bvc-leak-rate <1-6553500>  | 83 |
| 1.9.12 | flow-control force-ms-bucket-size <1-6553500>                                       | 83 |
| 1.9.13 | flow-control force-ms-leak-rate <1-6553500>   | 84 |
| 1.9.14 | flow-control-interval <1-10>  | 84 |
| 1.9.15 | gamma <0-62>  | 84 |
| 1.9.16 | gb-dialect (classclip-sns)  | 85 |
| 1.9.17 | gsmtap-category (dl-unknown dl-dummy dl-ctrl dl-data-gprs dl-data-egprs dl-ptch...  | 85 |
| 1.9.18 | mcs <1-9> [<1-9>]   | 86 |
| 1.9.19 | mcs link-quality-ranges mcs1 <0-35> mcs2 <0-35> <0-35> mcs3 <0-35> <0-35> mcs4 <... | 87 |
| 1.9.20 | mcs max <1-9> [<1-9>]   | 88 |
| 1.9.21 | neighbor resolution (A.B.C.D X::X:X) [<0-65535>]                                    | 89 |
| 1.9.22 | no cs   | 89 |
| 1.9.23 | no cs downgrade-threshold   | 90 |
| 1.9.24 | no cs max   | 90 |
| 1.9.25 | no cs threshold   | 91 |
| 1.9.26 | no dl-tbf-preemptive-retransmission   | 91 |
| 1.9.27 | no flow-control bucket-time   | 91 |
| 1.9.28 | no flow-control force-bvc-bucket-size   | 92 |
| 1.9.29 | no flow-control force-bvc-leak-rate   | 92 |
| 1.9.30 | no flow-control force-ms-bucket-size  | 93 |
| 1.9.31 | no flow-control force-ms-leak-rate  | 93 |
| 1.9.32 | no gsmtap-category (dl-unknown dl-dummy dl-ctrl dl-data-gprs dl-data-egprs dl-pt... | 94 |
| 1.9.33 | no mcs  | 95 |
| 1.9.34 | no mcs max  | 95 |
| 1.9.35 | no queue codel  | 95 |
| 1.9.36 | no queue hysteresis   | 96 |
| 1.9.37 | no queue idle-ack-delay   | 96 |
| 1.9.38 | no queue lifetime   | 97 |
| 1.9.39 | no two-phase-access   | 97 |
| 1.9.40 | pcu-socket PATH   | 97 |

|        |  |     |
|--------|--|-----|
| 1.9.41 | queue codel . . . . .                              | 98  |
| 1.9.42 | queue codel interval <1-1000> . . . . .            | 98  |
| 1.9.43 | queue hysteresis <1-65535> . . . . .               | 99  |
| 1.9.44 | queue idle-ack-delay <1-65535> . . . . .           | 99  |
| 1.9.45 | queue lifetime <1-65534> . . . . .                 | 100 |
| 1.9.46 | queue lifetime infinite . . . . .                  | 100 |
| 1.9.47 | timer [TNNNN] [(<0-2147483647> default)] . . . . . | 101 |
| 1.9.48 | two-phase-access . . . . .                         | 101 |
| 1.9.49 | window-size <0-1024> [<0-256>] . . . . .           | 102 |

# List of Tables

|     |                                  |   |
|-----|----------------------------------|---|
| 1.1 | VTY Parameter Patterns . . . . . | 1 |
| 1.2 | VTY port numbers . . . . .       | 1 |

# Chapter 1

## VTY reference

The Virtual Tele Type (VTY) has the concept of nodes and commands. This chapter lists all nodes and the commands that are available within the node. Each command can consist out of several words followed by a variable number of parameters. There are common patterns for the parameters, these include IPv4 addresses, number ranges, a word, a line of text and choice. The following will explain the commonly used patterns.

| Pattern                   | Example          | Explanation                                  |
|---------------------------|------------------|--|
| A.B.C.D                   | 127.0.0.1        | A IPv4 address                               |
| TEXT                      | example01        | A single string without any spaces, tabs     |
| .TEXT                     | Some information | A line of text                               |
| (OptionA OptionB OptionC) | OptionA          | A choice between a list of available options |
| <0-10>                    | 5                | A number from a range                        |

Table 1.1: VTY Parameter Patterns

The application is configured through the VTY. For configuring a system one needs to enter the **enable** node and then enter the **configure terminal** command. Then the configuration can be made according to the available commands. After the system has been configured one can use the **write** command to write the new configuration to the configuration file. The new file will be used after the application has been restarted.

The following table lists the TCP port numbers of the VTY for the various Osmocom GSM related programs as used on sysmocom products:

| Port Number | Software            |
|-------------|---------------------|
| 4240        | osmo-pcu            |
| 4241        | osmo-bts            |
| 4242        | osmo-nitb, osmo-bsc |
| 4243        | osmo-bsc_mgcp       |
| 4244        | osmo-bsc_nat        |
| 4245        | osmo-sgsn           |
| 4246        | osmo-gbproxy        |

Table 1.2: VTY port numbers

### 1.1 Common Commands

These commands are available on all VTY nodes. They are listed here only once, to unclutter the VTY reference.

### 1.1.1 end

#### Command

```
end
```

#### Parameters

end

End current mode and change to enable mode.

### 1.1.2 exit

#### Command

```
exit
```

#### Parameters

exit

Exit current mode and down to previous mode

### 1.1.3 help

#### Command

```
help
```

#### Parameters

help

Description of the interactive help system

### 1.1.4 list [with-flags]

#### Command

```
list [with-flags]
```

#### Parameters

list

Print command list

[with-flags]

Also print the VTY attribute flags

---

### 1.1.5 show running-config

#### Command

```
show running-config
```

#### Parameters

##### show

Show running system information

##### running-config

running configuration

### 1.1.6 show vty-attributes

#### Command

```
show vty-attributes
```

#### Parameters

##### show

Show running system information

##### vty-attributes

List of VTY attributes

### 1.1.7 show vty-attributes (application|library|global)

#### Command

```
show vty-attributes (application|library|global)
```

#### Parameters

##### show

Show running system information

##### vty-attributes

List of VTY attributes

##### application

Application specific attributes only

##### library

Library specific attributes only

##### global

Global attributes only

---

### 1.1.8 write

Command

```
write
```

Parameters

write

Write running configuration to memory, network, or terminal

### 1.1.9 write file [PATH]

Command

```
write file [PATH]
```

Parameters

write

Write running configuration to memory, network, or terminal

file

Write to configuration file

[PATH]

Set file path to store the config, or replace if already exists

### 1.1.10 write memory

Command

```
write memory
```

Parameters

write

Write running configuration to memory, network, or terminal

memory

Write configuration to the file (same as write file)

### 1.1.11 write terminal

Command

```
write terminal
```

Parameters

write

Write running configuration to memory, network, or terminal

terminal

Write to terminal

## 1.2 view

The view node is the default node when connecting to the VTY interface. This node does not require any additional permission and allows to introspect the application.

### 1.2.1 enable [expert-mode]

Command

```
enable [expert-mode]
```

Parameters

enable

Turn on privileged mode command

[expert-mode]

Enable the expert mode (show hidden commands)

### 1.2.2 logging color (0|1)

Command

```
logging color (0|1)
```

Parameters

logging

Configure logging

color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

### 1.2.3 logging disable

Command

```
logging disable
```

Parameters

logging

Configure logging

disable

Disables logging to this vty

---



### 1.2.4 logging enable

This command is required to make logging commands available on the telnet VTY.

Command

```
logging enable
```

Parameters

logging

Configure logging

enable

Enables logging to this vty

### 1.2.5 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

Command

```
logging filter all (0|1)
```

Parameters

logging

Configure logging

filter

Filter log messages

all

Do you want to log all messages?

0

Only print messages matched by other filters

1

Bypass filter and print all messages

### 1.2.6 logging level (csn1|l1if|rlcmac|rlcmacdata|rlcmacd|rlcmacul|rlcmacsched|rlcmacm...

Command

```
logging level (csn1|l1if|rlcmac|rlcmacdata|rlcmacd|rlcmacul|rlcmacsched|rlcmacmeas|tbf ↔
|tbfdl|tbful|ns|pcu|nacc|rim|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtpl ↔
|lstats|lgsup|loap|lss7|lsccp|lsua|lm3ua|lmgcp|ljibuf|lrspro|lms|lbssgp) (debug|info ↔
|notice|error|fatal)
```

## Parameters

### logging

Configure logging

### level

Set the log level for a specified category

### csn1

Concrete Syntax Notation One (CSN1)

### l1if

GPRS PCU L1 interface (L1IF)

### rlcmac

GPRS RLC/MAC layer (RLCMAC)

### rlcmacdata

GPRS RLC/MAC layer Data (RLCMAC)

### rlmacdl

GPRS RLC/MAC layer Downlink (RLCMAC)

### rlmacul

GPRS RLC/MAC layer Uplink (RLCMAC)

### rlmacsched

GPRS RLC/MAC layer Scheduling (RLCMAC)

### rlmacmeas

GPRS RLC/MAC layer Measurements (RLCMAC)

### tbf

Temporary Block Flow (TBF)

### tbfdl

Temporary Block Flow (TBF) Downlink

### tbful

Temporary Block Flow (TBF) Uplink

### ns

GPRS Network Service Protocol (NS)

### pcu

GPRS Packet Control Unit (PCU)

### nacc

Network Assisted Cell Change (NACC)

### rim

RAN Information Management (RIM)

### lglobal

Library-internal global log family

### llapd

LAPD in libosmogsm

---

---

linp  
A-bis Input Subsystem

lmux  
A-bis B-Subchannel TRAU Frame Multiplex

lmi  
A-bis Input Driver for Signalling

lmib  
A-bis Input Driver for B-Channels (voice)

lsms  
Layer3 Short Message Service (SMS)

lctrl  
Control Interface

lgtp  
GPRS GTP library

lstats  
Statistics messages and logging

lgsup  
Generic Subscriber Update Protocol

loap  
Osmocom Authentication Protocol

lss7  
libosmo-sigtran Signalling System 7

lsccp  
libosmo-sigtran SCCP Implementation

lsua  
libosmo-sigtran SCCP User Adaptation

lm3ua  
libosmo-sigtran MTP3 User Adaptation

lmgcp  
libosmo-mgcp Media Gateway Control Protocol

ljibuf  
libosmo-netif Jitter Buffer

lrspro  
Remote SIM protocol

lns  
GPRS NS layer

lbssgp  
GPRS BSSGP layer

---

**debug**

Log debug messages and higher levels

**info**

Log informational messages and higher levels

**notice**

Log noticeable messages and higher levels

**error**

Log error messages and higher levels

**fatal**

Log only fatal messages

### 1.2.7 logging level force-all (debug|info|notice|error|fatal)

**Command**

```
logging level force-all (debug|info|notice|error|fatal)
```

**Parameters****logging**

Configure logging

**level**

Set the log level for a specified category

**force-all**

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

**debug**

Log debug messages and higher levels

**info**

Log informational messages and higher levels

**notice**

Log noticeable messages and higher levels

**error**

Log error messages and higher levels

**fatal**

Log only fatal messages

### 1.2.8 logging level set-all (debug|info|notice|error|fatal)

#### Command

```
logging level set-all (debug|info|notice|error|fatal)
```

#### Parameters

##### logging

Configure logging

##### level

Set the log level for a specified category

##### set-all

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

##### debug

Log debug messages and higher levels

##### info

Log informational messages and higher levels

##### notice

Log noticeable messages and higher levels

##### error

Log error messages and higher levels

##### fatal

Log only fatal messages

### 1.2.9 logging print category (0|1)

#### Command

```
logging print category (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### category

Configure log message

##### 0

Don't prefix each log message

##### 1

Prefix each log message with category/subsystem name

---

### 1.2.10 logging print category-hex (0|1)

#### Command

```
logging print category-hex (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

### 1.2.11 logging print extended-timestamp (0|1)

#### Command

```
logging print extended-timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

### 1.2.12 logging print file (0|1|basename) [last]

#### Command

```
logging print file (0|1|basename) [last]
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### file

Configure log message

##### 0

Don't prefix each log message

##### 1

Prefix each log message with the source file and line

##### basename

Prefix each log message with the source file's basename (strip leading paths) and line

##### [last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

### 1.2.13 logging print level (0|1)

#### Command

```
logging print level (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### level

Configure log message

##### 0

Don't prefix each log message

##### 1

Prefix each log message with the log level name

### 1.2.14 logging print thread-id (0|1)

#### Command

```
logging print thread-id (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### thread-id

Configure log message logging Thread ID

0

Don't prefix each log message

1

Prefix each log message with current Thread ID

### 1.2.15 logging set-log-mask MASK

#### Command

```
logging set-log-mask MASK
```

#### Parameters

##### logging

Configure logging

##### set-log-mask

Set the logmask of this logging target

##### MASK

List of logging categories to log, e.g. 'abc:mno:xyz'. Available log categories depend on the specific application, refer to the 'logging level' command. Optionally add individual log levels like 'abc,1:mno,3:xyz,5', where the level numbers are LOGL\_DEBUG=1 LOGL\_INFO=3 LOGL\_NOTICE=5 LOGL\_ERROR=7 LOGL\_FATAL=8

### 1.2.16 logging timestamp (0|1)

#### Command

```
logging timestamp (0|1)
```

#### Parameters

---



**logging**

Configure logging

**timestamp**

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

**1.2.17 logp (csn1|l1if|rlcmac|rlcmacdata|rlcmacdl|rlcmacul|rlcmacsched|rlcmacmeas|tbf|t...****Command**

```
logp (csn1|l1if|rlcmac|rlcmacdata|rlcmacdl|rlcmacul|rlcmacsched|rlcmacmeas|tbf|tbfdl| ↵
      tbful|ns|pcu|nacc|rim|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats|lgsup ↵
      |loap|lss7|lscpp|lsua|lm3ua|lmgcp|ljibuf|lrspro|lns|lbssgp) (debug|info|notice| ↵
      error|fatal) .LOGMESSAGE
```

**Parameters****logp**

Print a message on all log outputs; useful for placing markers in test logs

**csn1**

Concrete Syntax Notation One (CSN1)

**l1if**

GPRS PCU L1 interface (L1IF)

**rlcmac**

GPRS RLC/MAC layer (RLCMAC)

**rlcmacdata**

GPRS RLC/MAC layer Data (RLCMAC)

**rlcmacdl**

GPRS RLC/MAC layer Downlink (RLCMAC)

**rlcmacul**

GPRS RLC/MAC layer Uplink (RLCMAC)

**rlcmacsched**

GPRS RLC/MAC layer Scheduling (RLCMAC)

**rlcmacmeas**

GPRS RLC/MAC layer Measurements (RLCMAC)

**tbf**

Temporary Block Flow (TBF)

**tbfdl**

Temporary Block Flow (TBF) Downlink

---

|         |   |
|---------|---|
| tbful   | Temporary Block Flow (TBF) Uplink         |
| ns      | GPRS Network Service Protocol (NS)        |
| pcu     | GPRS Packet Control Unit (PCU)            |
| nacc    | Network Assisted Cell Change (NACC)       |
| rim     | RAN Information Management (RIM)          |
| lglobal | Library-internal global log family        |
| llapd   | LAPD in libosmogsm                        |
| linp    | A-bis Input Subsystem                     |
| lmux    | A-bis B-Subchannel TRAU Frame Multiplex   |
| lmi     | A-bis Input Driver for Signalling         |
| lmib    | A-bis Input Driver for B-Channels (voice) |
| lsms    | Layer3 Short Message Service (SMS)        |
| lctrl   | Control Interface                         |
| lgtp    | GPRS GTP library                          |
| lstats  | Statistics messages and logging           |
| lgsup   | Generic Subscriber Update Protocol        |
| loap    | Osmocom Authentication Protocol           |
| lss7    | libosmo-sigtran Signalling System 7       |
| lsccp   | libosmo-sigtran SCCP Implementation       |

---

lsua  
libosmo-sigtran SCCP User Adaptation

lm3ua  
libosmo-sigtran MTP3 User Adaptation

lmgcp  
libosmo-mgcp Media Gateway Control Protocol

ljibuf  
libosmo-netif Jitter Buffer

lrspro  
Remote SIM protocol

lns  
GPRS NS layer

lbssgp  
GPRS BSSGP layer

debug  
Log debug messages and higher levels

info  
Log informational messages and higher levels

notice  
Log noticeable messages and higher levels

error  
Log error messages and higher levels

fatal  
Log only fatal messages

.LOGMESSAGE  
Arbitrary message to log on given category and log level

### 1.2.18 no logging level force-all

Command

```
no logging level force-all
```

Parameters

no

Negate a command or set its defaults

logging

Configure logging

level

Set the log level for a specified category

force-all

Release any globally forced log level set with 'logging level force-all <level>'

### 1.2.19 show alarms

#### Command

```
show alarms
```

#### Parameters

##### show

Show running system information

##### alarms

Show current logging configuration

### 1.2.20 show asciidoc counters

#### Command

```
show asciidoc counters
```

#### Parameters

##### show

Show running system information

##### asciidoc

Asciidoc generation

##### counters

Generate table of all registered counters

### 1.2.21 show bts pdch

#### Command

```
show bts pdch
```

#### Parameters

##### show

Show running system information

##### bts

BTS related functionality

##### pdch

PDCH timeslots

### 1.2.22 show bts statistics

#### Command

```
show bts statistics
```

#### Parameters

show

Show running system information

bts

BTS related functionality

statistics

Statistics

### 1.2.23 show bts-timer [TNNNN]

#### Command

```
show bts-timer [TNNNN]
```

#### Parameters

show

Show running system information

bts-timer

Show BTS controlled timers

[TNNNN]

T- or X-timer-number -- 3GPP compliant timer number of the format '1234' or 'T1234' or 't1234'; Osmocom-specific timer number of the format: 'X1234' or 'x1234'.

### 1.2.24 show cpu-sched threads

#### Command

```
show cpu-sched threads
```

#### Parameters

show

Show running system information

cpu-sched

Show Sched section information

threads

Show information about running threads)

---

### 1.2.25 show fsm NAME

#### Command

```
show fsm NAME
```

#### Parameters

##### show

Show running system information

##### fsm

Show information about finite state machines

##### NAME

Display information about a single named finite state machine

### 1.2.26 show fsm all

#### Command

```
show fsm all
```

#### Parameters

##### show

Show running system information

##### fsm

Show information about finite state machines

##### all

Display a list of all registered finite state machines

### 1.2.27 show fsm-instances NAME

#### Command

```
show fsm-instances NAME
```

#### Parameters

##### show

Show running system information

##### fsm-instances

Show information about finite state machine instances

##### NAME

Display a list of all FSM instances of the named finite state machine

---

### 1.2.28 show fsm-instances all

#### Command

```
show fsm-instances all
```

#### Parameters

##### show

Show running system information

##### fsm-instances

Show information about finite state machine instances

##### all

Display a list of all FSM instances of all finite state machine

### 1.2.29 show history

#### Command

```
show history
```

#### Parameters

##### show

Show running system information

##### history

Display the session command history

### 1.2.30 show logging vty

#### Command

```
show logging vty
```

#### Parameters

##### show

Show running system information

##### logging

Show current logging configuration

##### vty

Show current logging configuration for this vty

---

### 1.2.31 show ms all

#### Command

```
show ms all
```

#### Parameters

show

Show running system information

ms

information about MSs

all

All TBFs

### 1.2.32 show ms imsi IMSI

#### Command

```
show ms imsi IMSI
```

#### Parameters

show

Show running system information

ms

information about MSs

imsi

Select MS by IMSI

IMSI

IMSI

### 1.2.33 show ms tlli TLLI

#### Command

```
show ms tlli TLLI
```

#### Parameters

show

Show running system information

ms

information about MSs

tlli

Select MS by TLLI

TLLI

TLLI as hex



### 1.2.34 show online-help

#### Command

```
show online-help
```

#### Parameters

##### show

Show running system information

##### online-help

Online help

### 1.2.35 show rate-counters

#### Command

```
show rate-counters
```

#### Parameters

##### show

Show running system information

##### rate-counters

Show all rate counters

### 1.2.36 show stats

#### Command

```
show stats
```

#### Parameters

##### show

Show running system information

##### stats

Show statistical values

### 1.2.37 show stats level (global|peer|subscriber)

#### Command

```
show stats level (global|peer|subscriber)
```

#### Parameters

show

Show running system information

stats

Show statistical values

level

Set the maximum group level

global

Show global groups only

peer

Show global and network peer related groups

subscriber

Show global, peer, and subscriber groups

### 1.2.38 show talloc-context (application|all) (full|brief|DEPTH)

#### Command

```
show talloc-context (application|all) (full|brief|DEPTH)
```

#### Parameters

show

Show running system information

talloc-context

Show talloc memory hierarchy

application

Application's context

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

---

### 1.2.39 show talloc-context (application|all) (full|brief|DEPTH) filter REGEXP

#### Command

```
show talloc-context (application|all) (full|brief|DEPTH) filter REGEXP
```

#### Parameters

##### show

Show running system information

##### talloc-context

Show talloc memory hierarchy

##### application

Application's context

##### all

All contexts, if NULL-context tracking is enabled

##### full

Display a full talloc memory hierarchy

##### brief

Display a brief talloc memory hierarchy

##### DEPTH

Specify required maximal depth value

##### filter

Filter chunks using regular expression

##### REGEXP

Regular expression

### 1.2.40 show talloc-context (application|all) (full|brief|DEPTH) tree ADDRESS

#### Command

```
show talloc-context (application|all) (full|brief|DEPTH) tree ADDRESS
```

#### Parameters

##### show

Show running system information

##### talloc-context

Show talloc memory hierarchy

##### application

Application's context

##### all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

tree

Display only a specific memory chunk

ADDRESS

Chunk address (e.g. 0xdeadbeef)

### 1.2.41 show tbf (all|ccch|pacch)

Command

```
show tbf (all|ccch|pacch)
```

Parameters

show

Show running system information

tbf

information about TBFs

all

All TBFs

ccch

TBFs allocated via CCCH

pacch

TBFs allocated via PACCH

### 1.2.42 show timer [TNNNN]

Command

```
show timer [TNNNN]
```

Parameters

show

Show running system information

timer

Show PCU timers

[TNNNN]

T- or X-timer-number -- 3GPP compliant timer number of the format '1234' or 'T1234' or 't1234'; Osmocom-specific timer number of the format: 'X1234' or 'x1234'.

### 1.2.43 show version

#### Command

```
show version
```

#### Parameters

##### show

Show running system information

##### version

Displays program version

### 1.2.44 terminal length <0-512>

#### Command

```
terminal length <0-512>
```

#### Parameters

##### terminal

Set terminal line parameters

##### length

Set number of lines on a screen

##### <0-512>

Number of lines on screen (0 for no pausing)

### 1.2.45 terminal no length

#### Command

```
terminal no length
```

#### Parameters

##### terminal

Set terminal line parameters

##### no

Negate a command or set its defaults

##### length

Set number of lines on a screen

---

### 1.2.46 who

#### Command

```
who
```

#### Parameters

who

Display who is on vty

## 1.3 enable

The enable node is a privileged node, allowing to make changes to the configuration and to access further commands like 'configure'. All commands seen on the view node are also available here.

### 1.3.1 configure terminal

#### Command

```
configure terminal
```

#### Parameters

configure

Configuration from vty interface

terminal

Configuration terminal

### 1.3.2 copy running-config startup-config

#### Command

```
copy running-config startup-config
```

#### Parameters

copy

Copy configuration

running-config

Copy running config to...

startup-config

Copy running config to startup config (same as write file)

---

### 1.3.3 disable

#### Command

```
disable
```

#### Parameters

##### disable

Turn off privileged mode command

### 1.3.4 logging color (0|1)

#### Command

```
logging color (0|1)
```

#### Parameters

##### logging

Configure logging

##### color

Configure color-printing for log messages

##### 0

Don't use color for printing messages

##### 1

Use color for printing messages

### 1.3.5 logging disable

#### Command

```
logging disable
```

#### Parameters

##### logging

Configure logging

##### disable

Disables logging to this vty

---

### 1.3.6 logging enable

This command is required to make logging commands available on the telnet VTY.

Command

```
logging enable
```

Parameters

logging

Configure logging

enable

Enables logging to this vty

### 1.3.7 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

Command

```
logging filter all (0|1)
```

Parameters

logging

Configure logging

filter

Filter log messages

all

Do you want to log all messages?

0

Only print messages matched by other filters

1

Bypass filter and print all messages

### 1.3.8 logging level (csn1|l1if|rlcmac|rlcmacdata|rlcmacd|rlcmacul|rlcmacsched|rlcmacm...

Command

```
logging level (csn1|l1if|rlcmac|rlcmacdata|rlcmacd|rlcmacul|rlcmacsched|rlcmacmeas|tbf ↔
|tbfdl|tbful|ns|pcu|nacc|rim|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtpl ↔
|lstats|lgsup|loap|lss7|lsccp|lsua|lm3ua|lmgcp|ljibuf|lrspro|lms|lbssgp) (debug|info ↔
|notice|error|fatal)
```



## Parameters

### logging

Configure logging

### level

Set the log level for a specified category

### csn1

Concrete Syntax Notation One (CSN1)

### l1if

GPRS PCU L1 interface (L1IF)

### rlcmac

GPRS RLC/MAC layer (RLCMAC)

### rlcmacdata

GPRS RLC/MAC layer Data (RLCMAC)

### rlmacdl

GPRS RLC/MAC layer Downlink (RLCMAC)

### rlmacul

GPRS RLC/MAC layer Uplink (RLCMAC)

### rlmacsched

GPRS RLC/MAC layer Scheduling (RLCMAC)

### rlmacmeas

GPRS RLC/MAC layer Measurements (RLCMAC)

### tbf

Temporary Block Flow (TBF)

### tbfdl

Temporary Block Flow (TBF) Downlink

### tbful

Temporary Block Flow (TBF) Uplink

### ns

GPRS Network Service Protocol (NS)

### pcu

GPRS Packet Control Unit (PCU)

### nacc

Network Assisted Cell Change (NACC)

### rim

RAN Information Management (RIM)

### lglobal

Library-internal global log family

### llapd

LAPD in libosmogsm

---

---

linp  
A-bis Input Subsystem

lmux  
A-bis B-Subchannel TRAU Frame Multiplex

lmi  
A-bis Input Driver for Signalling

lmib  
A-bis Input Driver for B-Channels (voice)

lsms  
Layer3 Short Message Service (SMS)

lctrl  
Control Interface

lgtp  
GPRS GTP library

lstats  
Statistics messages and logging

lgsup  
Generic Subscriber Update Protocol

loap  
Osmocom Authentication Protocol

lss7  
libosmo-sigtran Signalling System 7

lsccp  
libosmo-sigtran SCCP Implementation

lsua  
libosmo-sigtran SCCP User Adaptation

lm3ua  
libosmo-sigtran MTP3 User Adaptation

lmgcp  
libosmo-mgcp Media Gateway Control Protocol

ljibuf  
libosmo-netif Jitter Buffer

lrspro  
Remote SIM protocol

lns  
GPRS NS layer

lbssgp  
GPRS BSSGP layer

---

**debug**

Log debug messages and higher levels

**info**

Log informational messages and higher levels

**notice**

Log noticeable messages and higher levels

**error**

Log error messages and higher levels

**fatal**

Log only fatal messages

### 1.3.9 logging level force-all (debug|info|notice|error|fatal)

**Command**

```
logging level force-all (debug|info|notice|error|fatal)
```

**Parameters****logging**

Configure logging

**level**

Set the log level for a specified category

**force-all**

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

**debug**

Log debug messages and higher levels

**info**

Log informational messages and higher levels

**notice**

Log noticeable messages and higher levels

**error**

Log error messages and higher levels

**fatal**

Log only fatal messages

---

### 1.3.10 logging level set-all (debug|info|notice|error|fatal)

#### Command

```
logging level set-all (debug|info|notice|error|fatal)
```

#### Parameters

##### logging

Configure logging

##### level

Set the log level for a specified category

##### set-all

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

##### debug

Log debug messages and higher levels

##### info

Log informational messages and higher levels

##### notice

Log noticeable messages and higher levels

##### error

Log error messages and higher levels

##### fatal

Log only fatal messages

### 1.3.11 logging print category (0|1)

#### Command

```
logging print category (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### category

Configure log message

##### 0

Don't prefix each log message

##### 1

Prefix each log message with category/subsystem name

---

### 1.3.12 logging print category-hex (0|1)

#### Command

```
logging print category-hex (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

### 1.3.13 logging print extended-timestamp (0|1)

#### Command

```
logging print extended-timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

### 1.3.14 logging print file (0|1|basename) [last]

#### Command

```
logging print file (0|1|basename) [last]
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### file

Configure log message

##### 0

Don't prefix each log message

##### 1

Prefix each log message with the source file and line

##### basename

Prefix each log message with the source file's basename (strip leading paths) and line

##### [last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

### 1.3.15 logging print level (0|1)

#### Command

```
logging print level (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### level

Configure log message

##### 0

Don't prefix each log message

##### 1

Prefix each log message with the log level name

### 1.3.16 logging print thread-id (0|1)

#### Command

```
logging print thread-id (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### thread-id

Configure log message logging Thread ID

0

Don't prefix each log message

1

Prefix each log message with current Thread ID

### 1.3.17 logging set-log-mask MASK

#### Command

```
logging set-log-mask MASK
```

#### Parameters

##### logging

Configure logging

##### set-log-mask

Set the logmask of this logging target

##### MASK

List of logging categories to log, e.g. 'abc:mno:xyz'. Available log categories depend on the specific application, refer to the 'logging level' command. Optionally add individual log levels like 'abc,1:mno,3:xyz,5', where the level numbers are LOGL\_DEBUG=1 LOGL\_INFO=3 LOGL\_NOTICE=5 LOGL\_ERROR=7 LOGL\_FATAL=8

### 1.3.18 logging timestamp (0|1)

#### Command

```
logging timestamp (0|1)
```

#### Parameters

---

**logging**

Configure logging

**timestamp**

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

**1.3.19 logp (csn1|l1if|rlcmac|rlcmacdata|rlcmacdl|rlcmacul|rlcmacsched|rlcmacmeas|tbf|t...****Command**

```
logp (csn1|l1if|rlcmac|rlcmacdata|rlcmacdl|rlcmacul|rlcmacsched|rlcmacmeas|tbf|tbfdl| ↵
      tbful|ns|pcu|nacc|rim|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats|lgsup ↵
      |loap|lss7|lscpp|lsua|lm3ua|lmgcp|ljibuf|lrspro|lns|lbssgp) (debug|info|notice| ↵
      error|fatal) .LOGMESSAGE
```

**Parameters****logp**

Print a message on all log outputs; useful for placing markers in test logs

**csn1**

Concrete Syntax Notation One (CSN1)

**l1if**

GPRS PCU L1 interface (L1IF)

**rlcmac**

GPRS RLC/MAC layer (RLCMAC)

**rlcmacdata**

GPRS RLC/MAC layer Data (RLCMAC)

**rlcmacdl**

GPRS RLC/MAC layer Downlink (RLCMAC)

**rlcmacul**

GPRS RLC/MAC layer Uplink (RLCMAC)

**rlcmacsched**

GPRS RLC/MAC layer Scheduling (RLCMAC)

**rlcmacmeas**

GPRS RLC/MAC layer Measurements (RLCMAC)

**tbf**

Temporary Block Flow (TBF)

**tbfdl**

Temporary Block Flow (TBF) Downlink



---

|         |   |
|---------|---|
| tbful   | Temporary Block Flow (TBF) Uplink         |
| ns      | GPRS Network Service Protocol (NS)        |
| pcu     | GPRS Packet Control Unit (PCU)            |
| nacc    | Network Assisted Cell Change (NACC)       |
| rim     | RAN Information Management (RIM)          |
| lglobal | Library-internal global log family        |
| llapd   | LAPD in libosmogsm                        |
| linp    | A-bis Input Subsystem                     |
| lmux    | A-bis B-Subchannel TRAU Frame Multiplex   |
| lmi     | A-bis Input Driver for Signalling         |
| lmib    | A-bis Input Driver for B-Channels (voice) |
| lsms    | Layer3 Short Message Service (SMS)        |
| lctrl   | Control Interface                         |
| lgtp    | GPRS GTP library                          |
| lstats  | Statistics messages and logging           |
| lgsup   | Generic Subscriber Update Protocol        |
| loap    | Osmocom Authentication Protocol           |
| lss7    | libosmo-sigtran Signalling System 7       |
| lsccp   | libosmo-sigtran SCCP Implementation       |

---

lsua  
libosmo-sigtran SCCP User Adaptation

lm3ua  
libosmo-sigtran MTP3 User Adaptation

lmgcp  
libosmo-mgcp Media Gateway Control Protocol

ljibuf  
libosmo-netif Jitter Buffer

lrspro  
Remote SIM protocol

lns  
GPRS NS layer

lbssgp  
GPRS BSSGP layer

debug  
Log debug messages and higher levels

info  
Log informational messages and higher levels

notice  
Log noticeable messages and higher levels

error  
Log error messages and higher levels

fatal  
Log only fatal messages

.LOGMESSAGE  
Arbitrary message to log on given category and log level

### 1.3.20 no logging level force-all

Command

```
no logging level force-all
```

Parameters

no

Negate a command or set its defaults

logging

Configure logging

level

Set the log level for a specified category

force-all

Release any globally forced log level set with 'logging level force-all <level>'

### 1.3.21 show alarms

#### Command

```
show alarms
```

#### Parameters

##### show

Show running system information

##### alarms

Show current logging configuration

### 1.3.22 show asciidoc counters

#### Command

```
show asciidoc counters
```

#### Parameters

##### show

Show running system information

##### asciidoc

Asciidoc generation

##### counters

Generate table of all registered counters

### 1.3.23 show bts pdch

#### Command

```
show bts pdch
```

#### Parameters

##### show

Show running system information

##### bts

BTS related functionality

##### pdch

PDCH timeslots

### 1.3.24 show bts statistics

#### Command

```
show bts statistics
```

#### Parameters

show

Show running system information

bts

BTS related functionality

statistics

Statistics

### 1.3.25 show bts-timer [TNNNN]

#### Command

```
show bts-timer [TNNNN]
```

#### Parameters

show

Show running system information

bts-timer

Show BTS controlled timers

[TNNNN]

T- or X-timer-number -- 3GPP compliant timer number of the format '1234' or 'T1234' or 't1234'; Osmocom-specific timer number of the format: 'X1234' or 'x1234'.

### 1.3.26 show cpu-sched threads

#### Command

```
show cpu-sched threads
```

#### Parameters

show

Show running system information

cpu-sched

Show Sched section information

threads

Show information about running threads)

---

### 1.3.27 show fsm NAME

#### Command

```
show fsm NAME
```

#### Parameters

##### show

Show running system information

##### fsm

Show information about finite state machines

##### NAME

Display information about a single named finite state machine

### 1.3.28 show fsm all

#### Command

```
show fsm all
```

#### Parameters

##### show

Show running system information

##### fsm

Show information about finite state machines

##### all

Display a list of all registered finite state machines

### 1.3.29 show fsm-instances NAME

#### Command

```
show fsm-instances NAME
```

#### Parameters

##### show

Show running system information

##### fsm-instances

Show information about finite state machine instances

##### NAME

Display a list of all FSM instances of the named finite state machine

---

### 1.3.30 show fsm-instances all

#### Command

```
show fsm-instances all
```

#### Parameters

##### show

Show running system information

##### fsm-instances

Show information about finite state machine instances

##### all

Display a list of all FSM instances of all finite state machine

### 1.3.31 show history

#### Command

```
show history
```

#### Parameters

##### show

Show running system information

##### history

Display the session command history

### 1.3.32 show logging vty

#### Command

```
show logging vty
```

#### Parameters

##### show

Show running system information

##### logging

Show current logging configuration

##### vty

Show current logging configuration for this vty

---

### 1.3.33 show ms all

#### Command

```
show ms all
```

#### Parameters

show

Show running system information

ms

information about MSs

all

All TBFs

### 1.3.34 show ms imsi IMSI

#### Command

```
show ms imsi IMSI
```

#### Parameters

show

Show running system information

ms

information about MSs

imsi

Select MS by IMSI

IMSI

IMSI

### 1.3.35 show ms tlli TLLI

#### Command

```
show ms tlli TLLI
```

#### Parameters

show

Show running system information

ms

information about MSs

tlli

Select MS by TLLI

TLLI

TLLI as hex

### 1.3.36 show online-help

#### Command

```
show online-help
```

#### Parameters

show

Show running system information

online-help

Online help

### 1.3.37 show rate-counters

#### Command

```
show rate-counters
```

#### Parameters

show

Show running system information

rate-counters

Show all rate counters

### 1.3.38 show startup-config

#### Command

```
show startup-config
```

#### Parameters

show

Show running system information

startup-config

Contentes of startup configuration

### 1.3.39 show stats

#### Command

```
show stats
```

#### Parameters

show

Show running system information

stats

Show statistical values



### 1.3.40 show stats level (global|peer|subscriber)

#### Command

```
show stats level (global|peer|subscriber)
```

#### Parameters

show

Show running system information

stats

Show statistical values

level

Set the maximum group level

global

Show global groups only

peer

Show global and network peer related groups

subscriber

Show global, peer, and subscriber groups

### 1.3.41 show talloc-context (application|all) (full|brief|DEPTH)

#### Command

```
show talloc-context (application|all) (full|brief|DEPTH)
```

#### Parameters

show

Show running system information

talloc-context

Show talloc memory hierarchy

application

Application's context

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

---

### 1.3.42 show talloc-context (application|all) (full|brief|DEPTH) filter REGEXP

#### Command

```
show talloc-context (application|all) (full|brief|DEPTH) filter REGEXP
```

#### Parameters

##### show

Show running system information

##### talloc-context

Show talloc memory hierarchy

##### application

Application's context

##### all

All contexts, if NULL-context tracking is enabled

##### full

Display a full talloc memory hierarchy

##### brief

Display a brief talloc memory hierarchy

##### DEPTH

Specify required maximal depth value

##### filter

Filter chunks using regular expression

##### REGEXP

Regular expression

### 1.3.43 show talloc-context (application|all) (full|brief|DEPTH) tree ADDRESS

#### Command

```
show talloc-context (application|all) (full|brief|DEPTH) tree ADDRESS
```

#### Parameters

##### show

Show running system information

##### talloc-context

Show talloc memory hierarchy

##### application

Application's context

##### all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

tree

Display only a specific memory chunk

ADDRESS

Chunk address (e.g. 0xdeadbeef)

### 1.3.44 show tbf (all|ccch|pacch)

Command

```
show tbf (all|ccch|pacch)
```

Parameters

show

Show running system information

tbf

information about TBFs

all

All TBFs

ccch

TBFs allocated via CCCH

pacch

TBFs allocated via PACCH

### 1.3.45 show timer [TNNNN]

Command

```
show timer [TNNNN]
```

Parameters

show

Show running system information

timer

Show PCU timers

[TNNNN]

T- or X-timer-number -- 3GPP compliant timer number of the format '1234' or 'T1234' or 't1234'; Osmocom-specific timer number of the format: 'X1234' or 'x1234'.

### 1.3.46 show version

#### Command

```
show version
```

#### Parameters

##### show

Show running system information

##### version

Displays program version

### 1.3.47 stats report

#### Command

```
stats report
```

#### Parameters

##### stats

Stats related commands

##### report

Manurally trigger reporting of stats

### 1.3.48 stats reset

#### Command

```
stats reset
```

#### Parameters

##### stats

Stats related commands

##### reset

Reset all stats

### 1.3.49 terminal length <0-512>

#### Command

```
terminal length <0-512>
```

#### Parameters

##### terminal

Set terminal line parameters

##### length

Set number of lines on a screen

##### <0-512>

Number of lines on screen (0 for no pausing)

### 1.3.50 terminal monitor

#### Command

```
terminal monitor
```

#### Parameters

##### terminal

Set terminal line parameters

##### monitor

Copy debug output to the current terminal line

### 1.3.51 terminal no length

#### Command

```
terminal no length
```

#### Parameters

##### terminal

Set terminal line parameters

##### no

Negate a command or set its defaults

##### length

Set number of lines on a screen

---

### 1.3.52 terminal no monitor

#### Command

```
terminal no monitor
```

#### Parameters

##### terminal

Set terminal line parameters

##### no

Negate a command or set its defaults

##### monitor

Copy debug output to the current terminal line

### 1.3.53 who

#### Command

```
who
```

#### Parameters

##### who

Display who is on vty

## 1.4 config

The config node is the root for all configuration commands, which are identical to the config file format. Changes made on the telnet VTY can be made persistent with the 'write file' command.

### 1.4.1 banner motd default

#### Command

```
banner motd default
```

#### Parameters

##### banner

Set banner string

##### motd

Strings for motd

##### default

Default string

---

### 1.4.2 banner motd file [FILE]

#### Command

```
banner motd file [FILE]
```

#### Parameters

##### banner

Set banner

##### motd

Banner for motd

##### file

Banner from a file

##### [FILE]

Filename

### 1.4.3 cpu-sched

#### Command

```
cpu-sched
```

#### Parameters

##### cpu-sched

Configure CPU Scheduler related settings

### 1.4.4 enable password (8|) WORD

#### Command

```
enable password (8|) WORD
```

#### Parameters

##### enable

Modify enable password parameters

##### password

Assign the privileged level password

##### 8

Specifies a HIDDEN password will follow

##### dummy string

##### WORD

The HIDDEN 'enable' password string

---

### 1.4.5 enable password LINE

#### Command

```
enable password LINE
```

#### Parameters

##### enable

Modify enable password parameters

##### password

Assign the privileged level password

##### LINE

The UNENCRYPTED (cleartext) 'enable' password

### 1.4.6 hostname WORD

#### Command

```
hostname WORD
```

#### Parameters

##### hostname

Set system's network name

##### WORD

This system's network name

### 1.4.7 line vty

#### Command

```
line vty
```

#### Parameters

##### line

Configure a terminal line

##### vtty

Virtual terminal



### 1.4.8 log alarms <2-32700>

#### Command

```
log alarms <2-32700>
```

#### Parameters

log

Configure logging sub-system

alarms

Logging alarms to osmo\_strrb

<2-32700>

Maximum number of messages to log

### 1.4.9 log file .FILENAME

#### Command

```
log file .FILENAME
```

#### Parameters

log

Configure logging sub-system

file

Logging to text file

.FILENAME

Filename

### 1.4.10 log gsmtap [HOSTNAME]

#### Command

```
log gsmtap [HOSTNAME]
```

#### Parameters

log

Configure logging sub-system

gsmtap

Logging via GSMTAP

[HOSTNAME]

Host name to send the GSMTAP logging to (UDP port 4729)

---

### 1.4.11 log stderr

#### Command

```
log stderr
```

#### Parameters

log

Configure logging sub-system

stderr

Logging via STDERR of the process

### 1.4.12 log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)

#### Command

```
log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)
```

#### Parameters

log

Configure logging sub-system

syslog

Logging via syslog

authpriv

Security/authorization messages facility

cron

Clock daemon (cron/at) facility

daemon

General system daemon facility

ftp

Ftp daemon facility

lpr

Line printer facility

mail

Mail facility

news

News facility

user

Generic facility

uucp

UUCP facility

---

### 1.4.13 log syslog local <0-7>

#### Command

```
log syslog local <0-7>
```

#### Parameters

log

Configure logging sub-system

syslog

Logging via syslog

local

Syslog LOCAL facility

<0-7>

Local facility number

### 1.4.14 log systemd-journal [raw]

#### Command

```
log systemd-journal [raw]
```

#### Parameters

log

Configure logging sub-system

systemd-journal

Logging to systemd-journal

[raw]

Offload rendering of the meta information (location, category) to systemd

### 1.4.15 no banner motd

#### Command

```
no banner motd
```

#### Parameters

no

Negate a command or set its defaults

banner

Set banner string

motd

Strings for motd

### 1.4.16 no enable password

#### Command

```
no enable password
```

#### Parameters

no

Negate a command or set its defaults

enable

Modify enable password parameters

password

Assign the privileged level password

### 1.4.17 no hostname [HOSTNAME]

#### Command

```
no hostname [HOSTNAME]
```

#### Parameters

no

Negate a command or set its defaults

hostname

Reset system's network name

[HOSTNAME]

Host name of this router

### 1.4.18 no log alarms

#### Command

```
no log alarms
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

alarms

Logging alarms to osmo\_strrb

---

### 1.4.19 no log file .FILENAME

#### Command

```
no log file .FILENAME
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

file

Logging to text file

.FILENAME

Filename

### 1.4.20 no log stderr

#### Command

```
no log stderr
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

stderr

Logging via STDERR of the process

### 1.4.21 no log syslog

#### Command

```
no log syslog
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

syslog

Logging via syslog

### 1.4.22 no log systemd-journal

#### Command

```
no log systemd-journal
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

systemd-journal

Logging to systemd-journal

### 1.4.23 no service advanced-vty

#### Command

```
no service advanced-vty
```

#### Parameters

no

Negate a command or set its defaults

service

Set up miscellaneous service

advanced-vty

Enable advanced mode vty interface

### 1.4.24 no service terminal-length [<0-512>]

#### Command

```
no service terminal-length [<0-512>]
```

#### Parameters

no

Negate a command or set its defaults

service

Set up miscellaneous service

terminal-length

System wide terminal length configuration

[<0-512>]

Number of lines of VTY (0 means no line control)

---

### 1.4.25 no stats reporter log

#### Command

```
no stats reporter log
```

#### Parameters

no

Negate a command or set its defaults

stats

Configure stats sub-system

reporter

Configure a stats reporter

log

Report to the logger

### 1.4.26 no stats reporter statsd

#### Command

```
no stats reporter statsd
```

#### Parameters

no

Negate a command or set its defaults

stats

Configure stats sub-system

reporter

Configure a stats reporter

statsd

Report to a STATSD server

### 1.4.27 password (8|) WORD

#### Command

```
password (8|) WORD
```

#### Parameters

password

Assign the terminal connection password

8

Specifies a HIDDEN password will follow

dummy string

WORD

The HIDDEN line password string

---

### 1.4.28 password LINE

#### Command

```
password LINE
```

#### Parameters

##### password

Assign the terminal connection password

##### LINE

The UNENCRYPTED (cleartext) line password

### 1.4.29 pcu

#### Command

```
pcu
```

#### Global attributes

##### Flag: !

This command applies immediately

#### Parameters

##### pcu

BTS specific configure

### 1.4.30 service advanced-vty

#### Command

```
service advanced-vty
```

#### Parameters

##### service

Set up miscellaneous service

##### advanced-vty

Enable advanced mode vty interface

---



### 1.4.31 service terminal-length <0-512>

#### Command

```
service terminal-length <0-512>
```

#### Parameters

##### service

Set up miscellaneous service

##### terminal-length

System wide terminal length configuration

##### <0-512>

Number of lines of VTY (0 means no line control)

### 1.4.32 show history

#### Command

```
show history
```

#### Parameters

##### show

Show running system information

##### history

Display the session command history

### 1.4.33 stats interval <0-65535>

#### Command

```
stats interval <0-65535>
```

#### Parameters

##### stats

Configure stats sub-system

##### interval

Set the reporting interval

##### <0-65535>

Interval in seconds (0 disables the reporting interval)

---

### 1.4.34 stats reporter log

#### Command

```
stats reporter log
```

#### Parameters

stats

Configure stats sub-system

reporter

Configure a stats reporter

log

Report to the logger

### 1.4.35 stats reporter statsd

#### Command

```
stats reporter statsd
```

#### Parameters

stats

Configure stats sub-system

reporter

Configure a stats reporter

statsd

Report to a STATSD server

## 1.5 config-log

The log node is commonly available in all Osmocom programs and allows configuring logging to stderr and/or log files, including logging category and level filtering as well as output formatting options. Note that the 'logging enable' command is required to make logging commands available on the telnet VTY.

### 1.5.1 logging color (0|1)

#### Command

```
logging color (0|1)
```

#### Parameters

**logging**

Configure logging

**color**

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

**1.5.2 logging filter all (0|1)**

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

**Command**

```
logging filter all (0|1)
```

**Parameters****logging**

Configure logging

**filter**

Filter log messages

all

Do you want to log all messages?

0

Only print messages matched by other filters

1

Bypass filter and print all messages

**1.5.3 logging level (csn1|l1if|rlcmac|rlcmacdata|rlcmacd|rlcmacul|rlcmacsched|rlcmacm...****Command**

```
logging level (csn1|l1if|rlcmac|rlcmacdata|rlcmacd|rlcmacul|rlcmacsched|rlcmacmeas|tbfdl|tbful|ns|pcu|nacc|rim|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats|lgsup|loap|lss7|lsccp|lsua|lm3ua|lmgcp|ljibuf|lrspro|lms|lbssgp) (debug|info|notice|error|fatal)
```

**Parameters**

logging

Configure logging

level

Set the log level for a specified category

csn1

Concrete Syntax Notation One (CSN1)

l1if

GPRS PCU L1 interface (L1IF)

rlcmac

GPRS RLC/MAC layer (RLCMAC)

rlmacdata

GPRS RLC/MAC layer Data (RLCMAC)

rlmacdl

GPRS RLC/MAC layer Downlink (RLCMAC)

rlmacul

GPRS RLC/MAC layer Uplink (RLCMAC)

rlmacsched

GPRS RLC/MAC layer Scheduling (RLCMAC)

rlmacmeas

GPRS RLC/MAC layer Measurements (RLCMAC)

tbf

Temporary Block Flow (TBF)

tbfdl

Temporary Block Flow (TBF) Downlink

tbful

Temporary Block Flow (TBF) Uplink

ns

GPRS Network Service Protocol (NS)

pcu

GPRS Packet Control Unit (PCU)

nacc

Network Assisted Cell Change (NACC)

rim

RAN Information Management (RIM)

lglobal

Library-internal global log family

llapd

LAPD in libosmogsm

---

---

linp  
A-bis Input Subsystem

lmux  
A-bis B-Subchannel TRAU Frame Multiplex

lmi  
A-bis Input Driver for Signalling

lmib  
A-bis Input Driver for B-Channels (voice)

lsms  
Layer3 Short Message Service (SMS)

lctrl  
Control Interface

lgtp  
GPRS GTP library

lstats  
Statistics messages and logging

lgsup  
Generic Subscriber Update Protocol

loap  
Osmocom Authentication Protocol

lss7  
libosmo-sigtran Signalling System 7

lsccp  
libosmo-sigtran SCCP Implementation

lsua  
libosmo-sigtran SCCP User Adaptation

lm3ua  
libosmo-sigtran MTP3 User Adaptation

lmgcp  
libosmo-mgcp Media Gateway Control Protocol

ljibuf  
libosmo-netif Jitter Buffer

lrspro  
Remote SIM protocol

lns  
GPRS NS layer

lbssgp  
GPRS BSSGP layer

---

**debug**

Log debug messages and higher levels

**info**

Log informational messages and higher levels

**notice**

Log noticeable messages and higher levels

**error**

Log error messages and higher levels

**fatal**

Log only fatal messages

### 1.5.4 logging level force-all (debug|info|notice|error|fatal)

**Command**

```
logging level force-all (debug|info|notice|error|fatal)
```

**Parameters****logging**

Configure logging

**level**

Set the log level for a specified category

**force-all**

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

**debug**

Log debug messages and higher levels

**info**

Log informational messages and higher levels

**notice**

Log noticeable messages and higher levels

**error**

Log error messages and higher levels

**fatal**

Log only fatal messages

---

### 1.5.5 logging level set-all (debug|info|notice|error|fatal)

#### Command

```
logging level set-all (debug|info|notice|error|fatal)
```

#### Parameters

##### logging

Configure logging

##### level

Set the log level for a specified category

##### set-all

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

##### debug

Log debug messages and higher levels

##### info

Log informational messages and higher levels

##### notice

Log noticeable messages and higher levels

##### error

Log error messages and higher levels

##### fatal

Log only fatal messages

### 1.5.6 logging print category (0|1)

#### Command

```
logging print category (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### category

Configure log message

##### 0

Don't prefix each log message

##### 1

Prefix each log message with category/subsystem name

---

### 1.5.7 logging print category-hex (0|1)

#### Command

```
logging print category-hex (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

### 1.5.8 logging print extended-timestamp (0|1)

#### Command

```
logging print extended-timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn



### 1.5.9 logging print file (0|1|basename) [last]

#### Command

```
logging print file (0|1|basename) [last]
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### file

Configure log message

##### 0

Don't prefix each log message

##### 1

Prefix each log message with the source file and line

##### basename

Prefix each log message with the source file's basename (strip leading paths) and line

##### [last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

### 1.5.10 logging print level (0|1)

#### Command

```
logging print level (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### level

Configure log message

##### 0

Don't prefix each log message

##### 1

Prefix each log message with the log level name

---

### 1.5.11 logging print thread-id (0|1)

#### Command

```
logging print thread-id (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### thread-id

Configure log message logging Thread ID

0

Don't prefix each log message

1

Prefix each log message with current Thread ID

### 1.5.12 logging timestamp (0|1)

#### Command

```
logging timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

### 1.5.13 no logging level force-all

#### Command

```
no logging level force-all
```

#### Parameters

---

no

Negate a command or set its defaults

logging

Configure logging

level

Set the log level for a specified category

force-all

Release any globally forced log level set with 'logging level force-all <level>'

## 1.6 config-stats

### 1.6.1 disable

Command

```
disable
```

Parameters

disable

Disable the reporter

### 1.6.2 enable

Command

```
enable
```

Parameters

enable

Enable the reporter

### 1.6.3 flush-period <0-65535>

Command

```
flush-period <0-65535>
```

Parameters

flush-period

Configure stats sub-system

<0-65535>

Send all stats even if they have not changed (i.e. force the flush) every N-th reporting interval. Set to 0 to disable regular flush (default).

### 1.6.4 level (global|peer|subscriber)

#### Command

```
level (global|peer|subscriber)
```

#### Parameters

##### level

Set the maximum group level

##### global

Report global groups only

##### peer

Report global and network peer related groups

##### subscriber

Report global, peer, and subscriber groups

### 1.6.5 local-ip ADDR

#### Command

```
local-ip ADDR
```

#### Parameters

##### local-ip

Set the IP address to which we bind locally

##### ADDR

IP Address

### 1.6.6 mtu <100-65535>

#### Command

```
mtu <100-65535>
```

#### Parameters

##### mtu

Set the maximum packet size

##### <100-65535>

Size in byte

---

### 1.6.7 no local-ip

#### Command

```
no local-ip
```

#### Parameters

no

Negate a command or set its defaults

local-ip

Set the IP address to which we bind locally

### 1.6.8 no mtu

#### Command

```
no mtu
```

#### Parameters

no

Negate a command or set its defaults

mtu

Set the maximum packet size

### 1.6.9 no prefix

#### Command

```
no prefix
```

#### Parameters

no

Negate a command or set its defaults

prefix

Set the item name prefix

### 1.6.10 prefix PREFIX

#### Command

```
prefix PREFIX
```

#### Parameters

prefix

Set the item name prefix

PREFIX

The prefix string

### 1.6.11 remote-ip ADDR

#### Command

```
remote-ip ADDR
```

#### Parameters

##### remote-ip

Set the remote IP address to which we connect

##### ADDR

IP Address

### 1.6.12 remote-port <1-65535>

#### Command

```
remote-port <1-65535>
```

#### Parameters

##### remote-port

Set the remote port to which we connect

##### <1-65535>

Remote port number

## 1.7 config-line

### 1.7.1 bind A.B.C.D [<0-65535>]

#### Command

```
bind A.B.C.D [<0-65535>]
```

#### Parameters

##### bind

Accept VTY telnet connections on local interface

##### A.B.C.D

Local interface IP address (default: 127.0.0.1)

##### [<0-65535>]

Local TCP port number

---

### 1.7.2 login

#### Command

```
login
```

#### Parameters

login

Enable password checking

### 1.7.3 no login

#### Command

```
no login
```

#### Parameters

no

Negate a command or set its defaults

login

Enable password checking

## 1.8 config-cpu-sched

### 1.8.1 cpu-affinity (self|all|<0-4294967295>|THREADNAME) CPUHEXMASK [delay]

#### Command

```
cpu-affinity (self|all|<0-4294967295>|THREADNAME) CPUHEXMASK [delay]
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

cpu-affinity

Set CPU affinity mask on a (group of) thread(s)

self

Set CPU affinity mask on thread running the VTY

all

Set CPU affinity mask on all process' threads

---

<0-4294967295>

Set CPU affinity mask on a thread with specified PID

THREADNAME

Set CPU affinity mask on a thread with specified thread name

CPUHEXMASK

CPU affinity mask

[delay]

If set, delay applying the affinity mask now and let the app handle it at a later point

## 1.8.2 policy rr <1-32>

Command

```
policy rr <1-32>
```

Global attributes

Flag: !

This command applies immediately

Parameters

policy

Set the scheduling policy to use for the process

rr

Use the SCHED\_RR real-time scheduling algorithm

<1-32>

Set the SCHED\_RR real-time priority

## 1.9 config-pcu

### 1.9.1 alloc-algorithm (a|b|dynamic)

Command

```
alloc-algorithm (a|b|dynamic)
```

Global attributes

Flag: !

This command applies immediately

Parameters

---



### alloc-algorithm

Select slot allocation algorithm to use when assigning timeslots on PACCH

a

Single slot is assigned only

b

Multiple slots are assigned for semi-duplex operation

dynamic

Dynamically select the algorithm based on the system state

## 1.9.2 cs <1-4> [<1-4>]

### Command

```
cs <1-4> [<1-4>]
```

### Global attributes

Flag: !

This command applies immediately

### Parameters

cs

Coding Scheme configuration

<1-4>

Initial CS value to be used (overrides BTS config)

[<1-4>]

Use a different initial CS value for the uplink

## 1.9.3 cs downgrade-threshold <1-10000>

### Command

```
cs downgrade-threshold <1-10000>
```

### Global attributes

Flag: !

This command applies immediately

### Parameters

cs

Coding Scheme configuration

downgrade-threshold

set threshold for data size based downlink (M)CS downgrade

<1-10000>

downgrade if less octets left

### 1.9.4 cs link-quality-ranges cs1 <0-35> cs2 <0-35> <0-35> cs3 <0-35> <0-35> cs4 <0-35>

#### Command

```
cs link-quality-ranges cs1 <0-35> cs2 <0-35> <0-35> cs3 <0-35> <0-35> cs4 <0-35>
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

cs

Coding Scheme configuration

link-quality-ranges

Set link quality ranges for each uplink CS

cs1

Set quality range for CS-1 (high value only)

<0-35>

CS-1 high (dB)

cs2

Set quality range for CS-2

<0-35>

CS-2 low (dB)

<0-35>

CS-2 high (dB)

cs3

Set quality range for CS-3

<0-35>

CS-3 low (dB)

<0-35>

CS-3 high (dB)

cs4

Set quality range for CS-4 (low value only)

<0-35>

CS-4 low (dB)

### 1.9.5 cs max <1-4> [<1-4>]

#### Command

```
cs max <1-4> [<1-4>]
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

cs

Coding Scheme configuration

max

Set maximum values for adaptive CS selection (overrides BTS config)

<1-4>

Maximum CS value to be used

[<1-4>]

Use a different maximum CS value for the uplink

### 1.9.6 cs threshold <0-100> <0-100>

#### Command

```
cs threshold <0-100> <0-100>
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

cs

Coding Scheme configuration

threshold

set thresholds for error rate based downlink (M)CS adjustment

<0-100>

lower limit in %

<0-100>

upper limit in %

### 1.9.7 dl-tbf-preemptive-retransmission

#### Command

```
dl-tbf-preemptive-retransmission
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

dl-tbf-preemptive-retransmission

retransmit blocks even before the MS had a chance to receive them (better throughput, less readable traces) (enabled by default)

### 1.9.8 egprs dl arq-type (spb|arq2)

#### Command

```
egprs dl arq-type (spb|arq2)
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

egprs

EGPRS configuration

dl

downlink specific configuration

arq-type

ARQ options

spb

enable SPB(ARQ1) support

arq2

enable ARQ2 support

### 1.9.9 flow-control bucket-time <1-65534>

#### Command

```
flow-control bucket-time <1-65534>
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

flow-control

BSSGP Flow Control configuration

bucket-time

Set target downlink maximum queueing time (only affects the advertised bucket size)

<1-65534>

Time in centi-seconds

### 1.9.10 flow-control force-bvc-bucket-size <1-6553500>

#### Command

```
flow-control force-bvc-bucket-size <1-6553500>
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

flow-control

BSSGP Flow Control configuration

force-bvc-bucket-size

Force a fixed value for the BVC bucket size

<1-6553500>

Bucket size in octets

### 1.9.11 flow-control force-bvc-leak-rate <1-6553500>

#### Command

```
flow-control force-bvc-leak-rate <1-6553500>
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

flow-control

BSSGP Flow Control configuration

force-bvc-leak-rate

Force a fixed value for the BVC leak rate

<1-6553500>

Leak rate in bit/s

### 1.9.12 flow-control force-ms-bucket-size <1-6553500>

#### Command

```
flow-control force-ms-bucket-size <1-6553500>
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

flow-control

BSSGP Flow Control configuration

force-ms-bucket-size

Force a fixed value for the default MS bucket size

<1-6553500>

Bucket size in octets

### 1.9.13 flow-control force-ms-leak-rate <1-6553500>

#### Command

```
flow-control force-ms-leak-rate <1-6553500>
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

flow-control

BSSGP Flow Control configuration

force-ms-leak-rate

Force a fixed value for the default MS leak rate

<1-6553500>

Leak rate in bit/s

### 1.9.14 flow-control-interval <1-10>

#### Command

```
flow-control-interval <1-10>
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

flow-control-interval

Interval between sending subsequent Flow Control PDUs

<1-10>

Interval time in seconds

### 1.9.15 gamma <0-62>

#### Command

```
gamma <0-62>
```

#### Global attributes

---

Flag: !

This command applies immediately

Parameters

gamma

Gamma parameter for MS power control in units of dB (see TS 05.08)

<0-62>

Gamma in even unit of dBs

### 1.9.16 gb-dialect (classic|ip-sns)

Command

```
gb-dialect (classic|ip-sns)
```

Application specific attributes

Flag: r

This command applies when the NS is reset

Parameters

gb-dialect

Select which Gb interface dialect to use

classic

Classic Gb interface with NS-{RESET,BLOCK,UNBLOCK} and static configuration

ip-sns

Modern Gb interface with IP-SNS (Sub Network Service) and dynamic configuration

### 1.9.17 gsmtap-category (dl-unknown|dl-dummy|dl-ctrl|dl-data-gprs|dl-data-egprs|dl-ptcch...

Command

```
gsmtap-category (dl-unknown|dl-dummy|dl-ctrl|dl-data-gprs|dl-data-egprs|dl-ptcch|dl- ↵
agch|dl-pch|ul-unknown|ul-dummy|ul-ctrl|ul-data-gprs|ul-data-egprs|ul-rach|ul-ptcch ↵
)
```

Parameters

gsmtap-category

GSMTAP Category

dl-unknown

Unknown / Unparseable / Erroneous Downlink Blocks

dl-dummy

Downlink Dummy Blocks



dl-ctrl  
Downlink Control Blocks

dl-data-gprs  
Downlink Data Blocks (GPRS)

dl-data-egprs  
Downlink Data Blocks (EGPRS)

dl-ptcch  
Downlink PTCCH Blocks

dl-agch  
Downlink AGCH Blocks

dl-pch  
Downlink PCH Blocks

ul-unknown  
Unknown / Unparseable / Erroneous Downlink Blocks

ul-dummy  
Uplink Dummy Blocks

ul-ctrl  
Uplink Control Blocks

ul-data-gprs  
Uplink Data Blocks (GPRS)

ul-data-egprs  
Uplink Data Blocks (EGPRS)

ul-rach  
Uplink RACH Bursts

ul-ptcch  
Uplink PTCCH Bursts

### 1.9.18 mcs <1-9> [<1-9>]

#### Command

```
mcs <1-9> [<1-9>]
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

mcs

Modulation and Coding Scheme configuration (EGPRS)

<1-9>

Initial MCS value to be used (default 1)

[<1-9>]

Use a different initial MCS value for the uplink

### 1.9.19 mcs link-quality-ranges mcs1 <0-35> mcs2 <0-35> <0-35> mcs3 <0-35> <0-35> mcs4 <...

#### Command

```
mcs link-quality-ranges mcs1 <0-35> mcs2 <0-35> <0-35> mcs3 <0-35> <0-35> mcs4 <0-35> ↵  
    <0-35> mcs5 <0-35> <0-35> mcs6 <0-35> <0-35> mcs7 <0-35> <0-35> mcs8 <0-35> <0-35> ↵  
    mcs9 <0-35>
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

mcs

Coding Scheme configuration

link-quality-ranges

Set link quality ranges for each uplink MCS

mcs1

Set quality range for MCS-1 (high value only)

<0-35>

MCS-1 high (dB)

mcs2

Set quality range for MCS-2

<0-35>

MCS-2 high (dB)

<0-35>

MCS-2 low (dB)

mcs3

Set quality range for MCS-3

<0-35>

MCS-3 high (dB)

<0-35>

MCS-3 low (dB)

mcs4

Set quality range for MCS-4

<0-35>

MCS-4 high (dB)

<0-35>

MCS-4 low (dB)

mcs5

Set quality range for MCS-5

<0-35>

MCS-5 high (dB)

<0-35>

MCS-5 low (dB)

mcs6

Set quality range for MCS-6

<0-35>

MCS-6 low (dB)

<0-35>

MCS-6 high (dB)

mcs7

Set quality range for MCS-7

<0-35>

MCS-7 low (dB)

<0-35>

MCS-7 high (dB)

mcs8

Set quality range for MCS-8

<0-35>

MCS-8 low (dB)

<0-35>

MCS-8 high (dB)

mcs9

Set quality range for MCS-9 (low value only)

<0-35>

MCS-9 low (dB)

### 1.9.20 mcs max <1-9> [<1-9>]

Command

```
mcs max <1-9> [<1-9>]
```

Global attributes

Flag: !

This command applies immediately

Parameters

mcs

Modulation and Coding Scheme configuration (EGPRS)

---

max

Set maximum values for adaptive CS selection (overrides BTS config)

<1-9>

Maximum MCS value to be used

[<1-9>]

Use a different maximum MCS value for the uplink

### 1.9.21 neighbor resolution (A.B.C.D|X:X::X:X) [<0-65535>]

Command

```
neighbor resolution (A.B.C.D|X:X::X:X) [<0-65535>]
```

Parameters

neighbor

Manage local and remote-BSS neighbor cells

resolution

Connect to Neighbor Resolution Service (CTRL interface) to given ip and port

A.B.C.D

IPv4 address to connect to

X:X::X:X

IPv6 address to connect to

[<0-65535>]

Port to connect to (default 4248)

### 1.9.22 no cs

Command

```
no cs
```

Global attributes

Flag: !

This command applies immediately

Parameters

no

Negate a command or set its defaults

cs

Coding Scheme configuration

### 1.9.23 no cs downgrade-threshold

#### Command

```
no cs downgrade-threshold
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

no

Negate a command or set its defaults

cs

Coding Scheme configuration

downgrade-threshold

set threshold for data size based downlink (M)CS downgrade

### 1.9.24 no cs max

#### Command

```
no cs max
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

no

Negate a command or set its defaults

cs

Coding Scheme configuration

max

Set maximum values for adaptive CS selection (overrides BTS config)

---

### 1.9.25 no cs threshold

#### Command

```
no cs threshold
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

no

Negate a command or set its defaults

cs

Coding Scheme configuration

threshold

set thresholds for error rate based downlink (M)CS adjustment

### 1.9.26 no dl-tbf-preemptive-retransmission

#### Command

```
no dl-tbf-preemptive-retransmission
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

no

Negate a command or set its defaults

dl-tbf-preemptive-retransmission

retransmit blocks even before the MS had a chance to receive them (better throughput, less readable traces)

### 1.9.27 no flow-control bucket-time

#### Command

```
no flow-control bucket-time
```

#### Global attributes

---

Flag: !

This command applies immediately

Parameters

no

Negate a command or set its defaults

flow-control

BSSGP Flow Control configuration

bucket-time

Set target downlink maximum queueing time (only affects the advertised bucket size)

### 1.9.28 no flow-control force-bvc-bucket-size

Command

```
no flow-control force-bvc-bucket-size
```

Global attributes

Flag: !

This command applies immediately

Parameters

no

Negate a command or set its defaults

flow-control

BSSGP Flow Control configuration

force-bvc-bucket-size

Force a fixed value for the BVC bucket size

### 1.9.29 no flow-control force-bvc-leak-rate

Command

```
no flow-control force-bvc-leak-rate
```

Global attributes

Flag: !

This command applies immediately

Parameters

no

Negate a command or set its defaults

flow-control

BSSGP Flow Control configuration

force-bvc-leak-rate

Force a fixed value for the BVC leak rate

---

### 1.9.30 no flow-control force-ms-bucket-size

#### Command

```
no flow-control force-ms-bucket-size
```

#### Global attributes

#### Flag: !

This command applies immediately

#### Parameters

##### no

Negate a command or set its defaults

##### flow-control

BSSGP Flow Control configuration

##### force-ms-bucket-size

Force a fixed value for the default MS bucket size

### 1.9.31 no flow-control force-ms-leak-rate

#### Command

```
no flow-control force-ms-leak-rate
```

#### Global attributes

#### Flag: !

This command applies immediately

#### Parameters

##### no

Negate a command or set its defaults

##### flow-control

BSSGP Flow Control configuration

##### force-ms-leak-rate

Force a fixed value for the default MS leak rate

---



### 1.9.32 no gsmtap-category (dl-unknown|dl-dummy|dl-ctrl|dl-data-gprs|dl-data-egprs|dl-pt...

#### Command

```
no gsmtap-category (dl-unknown|dl-dummy|dl-ctrl|dl-data-gprs|dl-data-egprs|dl-ptcch|dl- ↔  
agch|dl-pch|ul-unknown|ul-dummy|ul-ctrl|ul-data-gprs|ul-data-egprs|ul-rach|ul-ptcch ↔  
)
```

#### Parameters

no

Negate a command or set its defaults

gsmtap-category

GSMTAP Category

dl-unknown

Unknown / Unparseable / Erroneous Downlink Blocks

dl-dummy

Downlink Dummy Blocks

dl-ctrl

Downlink Control Blocks

dl-data-gprs

Downlink Data Blocks (GPRS)

dl-data-egprs

Downlink Data Blocks (EGPRS)

dl-ptcch

Downlink PTCCH Blocks

dl-agch

Downlink AGCH Blocks

dl-pch

Downlink PCH Blocks

ul-unknown

Unknown / Unparseable / Erroneous Downlink Blocks

ul-dummy

Uplink Dummy Blocks

ul-ctrl

Uplink Control Blocks

ul-data-gprs

Uplink Data Blocks (GPRS)

ul-data-egprs

Uplink Data Blocks (EGPRS)

ul-rach

Uplink RACH Bursts

ul-ptcch

Uplink PTCCH Bursts

### 1.9.33 no mcs

#### Command

```
no mcs
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

no

Negate a command or set its defaults

mcs

Modulation and Coding Scheme configuration (EGPRS)

### 1.9.34 no mcs max

#### Command

```
no mcs max
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

no

Negate a command or set its defaults

mcs

Modulation and Coding Scheme configuration (EGPRS)

max

Set maximum values for adaptive CS selection (overrides BTS config)

### 1.9.35 no queue codel

#### Command

```
no queue codel
```

#### Application specific attributes

---

Flag: s

This command applies when a new subscriber attaches

Parameters

no

Negate a command or set its defaults

queue

Packet queue options

codel

Set CoDel queue management

### 1.9.36 no queue hysteresis

Command

```
no queue hysteresis
```

Application specific attributes

Flag: n

This command applies when a new TBF is begins

Parameters

no

Negate a command or set its defaults

queue

Packet queue options

hysteresis

Set lifetime hysteresis of LLC frame in centi-seconds (continue discarding until lifetime-hysteresis is reached)

### 1.9.37 no queue idle-ack-delay

Command

```
no queue idle-ack-delay
```

Global attributes

Flag: !

This command applies immediately

Parameters

no

Negate a command or set its defaults

queue

Packet queue options

idle-ack-delay

Request an ACK after the last DL LLC frame in centi-seconds

---

### 1.9.38 no queue lifetime

#### Command

```
no queue lifetime
```

#### Application specific attributes

#### Flag: n

This command applies when a new TBF is begins

#### Parameters

#### no

Negate a command or set its defaults

#### queue

Packet queue options

#### lifetime

Disable lifetime limit of LLC frame (use value given by SGSN)

### 1.9.39 no two-phase-access

#### Command

```
no two-phase-access
```

#### Global attributes

#### Flag: !

This command applies immediately

#### Parameters

#### no

Negate a command or set its defaults

#### two-phase-access

Only use two phase access when requested my MS

### 1.9.40 pcu-socket PATH

#### Command

```
pcu-socket PATH
```

#### Parameters

#### pcu-socket

Configure the osmo-bts PCU socket file/path name

#### PATH

Path of the socket to connect to

---

### 1.9.41 queue codel

#### Command

```
queue codel
```

#### Application specific attributes

#### Flag: s

This command applies when a new subscriber attaches

#### Parameters

#### queue

Packet queue options

#### codel

Set CoDel queue management

### 1.9.42 queue codel interval <1-1000>

#### Command

```
queue codel interval <1-1000>
```

#### Application specific attributes

#### Flag: s

This command applies when a new subscriber attaches

#### Parameters

#### queue

Packet queue options

#### codel

Set CoDel queue management

#### interval

Specify interval

#### <1-1000>

Interval in centi-seconds

---

### 1.9.43 queue hysteresis <1-65535>

#### Command

```
queue hysteresis <1-65535>
```

#### Application specific attributes

Flag: n

This command applies when a new TBF is begins

#### Parameters

##### queue

Packet queue options

##### hysteresis

Set lifetime hysteresis of LLC frame in centi-seconds (continue discarding until lifetime-hysteresis is reached)

<1-65535>

Hysteresis in centi-seconds

### 1.9.44 queue idle-ack-delay <1-65535>

#### Command

```
queue idle-ack-delay <1-65535>
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

##### queue

Packet queue options

##### idle-ack-delay

Request an ACK after the last DL LLC frame in centi-seconds

<1-65535>

Idle ACK delay in centi-seconds

### 1.9.45 queue lifetime <1-65534>

#### Command

```
queue lifetime <1-65534>
```

#### Application specific attributes

Flag: n

This command applies when a new TBF is begins

#### Parameters

##### queue

Packet queue options

##### lifetime

Set lifetime limit of LLC frame in centi-seconds (overrides the value given by SGSN)

<1-65534>

Lifetime in centi-seconds

### 1.9.46 queue lifetime infinite

#### Command

```
queue lifetime infinite
```

#### Application specific attributes

Flag: n

This command applies when a new TBF is begins

#### Parameters

##### queue

Packet queue options

##### lifetime

Set lifetime limit of LLC frame in centi-seconds (overrides the value given by SGSN)

infinite

Infinite lifetime

### 1.9.47 timer [TNNNN] [( <0-2147483647>|default)]

#### Command

```
timer [TNNNN] [ (<0-2147483647>|default) ]
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

timer

Configure or show PCU timers

[TNNNN]

T- or X-timer-number -- 3GPP compliant timer number of the format '1234' or 'T1234' or 't1234'; Osmocom-specific timer number of the format: 'X1234' or 'x1234'.

[<0-2147483647>]

New timer value

[default]

Set to default timer value

### 1.9.48 two-phase-access

#### Command

```
two-phase-access
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

two-phase-access

Force two phase access when MS requests single phase access



### 1.9.49 window-size <0-1024> [<0-256>]

#### Command

```
window-size <0-1024> [<0-256>]
```

#### Application specific attributes

#### Flag: n

This command applies when a new TBF is begins

#### Parameters

##### window-size

Window size configuration ( $b + N\_PDCH * f$ )

##### <0-1024>

Base value (b)

##### [<0-256>]

Factor for number of PDCH (f)